



Sovereign Neoprene Primer

Is a high performance adhesion promoter and sealing compound promoter and sealing compound for use with Sovereign Floor Levelling Compounds.



Product Code
30806254

Description

Sovereign Neoprene Primer is a high performance adhesion promoter and sealing compound for use with Sovereign Floor Levelling Compound (underlayment) and Sovereign Hi Tech FLR (wear coat).

Can also be used as a primer prior to application of Sovereign cementitious tile adhesives on to difficult, dusty or porous substrates.

Form Supplied: Liquid concentrate

Pack Sizes: 5 Litres

Colour Range: Green

Contains: Neoprene latex compounds

Properties

Sovereign Neoprene Primer is used on non-absorbent surfaces such as steel, epoxy and polyester floors prior to laying a new Sovereign levelling compound. It is also used on dusty or porous surfaces to prevent unacceptably rapid drying of adhesives and underlayments. It is coloured green to provide the user with visual control of coverage uniformity.



Sovereign Neoprene Primer

Technical
Data Sheet **156**

PREPARATION

Floors must be sound, smooth, dry and free from contaminants that may prevent adhesion. Concrete and sand / cement screeds must be fully cured and any laitance or surface treatments removed. Existing adhesive must be mechanically removed until only a minimal, firmly bonded residue remains before priming. The temperature of the floor must be above 5°C and underfloor heating turned off at least 48 hours before and after application. Ensure that the subfloor has an effective damp-proof membrane

USAGE

NON-ABSORBENT SURFACES

For use prior to applying levelling compounds or adhesives to substrates such as terrazzo, power floated concrete, tiles, asphalt, steel, epoxy and polyester membranes.

Shake well before use and apply Sovereign Neoprene Primer to the entire surface neat and allow to dry completely.

ABSORBENT SURFACES

For use prior to applying levelling compounds or adhesives to substrates such as concrete, sand / cement screed, anhydrite and timber.

Dilute Sovereign Neoprene Primer 1 Part Primer to 4 parts of clean cold water. Stir until thoroughly dispersed then apply to the entire surface and allow to dry completely.

GENERAL

Use either a roller or broom to apply the primer, making sure to dampen before use. Once applied and after drying avoid trafficking of the subfloor.

COVERAGE

5 litres undiluted on non-absorbent surface = 50 m².

5 litres diluted on absorbent surface = 100 m².

Dependent on porosity and condition of the surface.

Storage: Between 5°C - 25°C.

Shelf Life: 12 months unopened.

HEALTH & SAFETY

- ! Avoid skin and eye contact.
- ! Handle only when wearing protective clothing.
- ! Wash splashes from skin with soap and water, flush eyes with copious amounts of water and seek medical attention if irritation persists.



Health & safety information
available on request



Important Disclaimer

The information given is in good faith based on experience and usage, however all recommendations are made without warranty or guarantee, since the conditions of use are beyond our control. All goods are sold in accordance with our Conditions of Sale, copies of which are available on request. Customers are advised that product, techniques and codes of practice are under constant review and changes occur without notice. Please ensure you have the latest updated information.



Sovereign
the gold standard in building products

Sovereign Support: 01229 870800 | www.sovchem.co.uk

FIND US HERE

